FLINQ CLIXX WIRELESS EARBUDS
FQC8222/8223/8224/8225

V1 User Manual

Congratulations on your purchase of this product!
Please read the following safety information and other important operating instructions carefully before you first use the new product. Pay special attention to safety information. Any result of incorrect handling and/or failure to follow the instructions may cause damage or injury.
Keep the instructions for future reference and pass on to any subsequent owner of the product.
Please note that some the operating instructions, illustrations and other information in this manual may differ slightly from your product due to subsequent changes made by the manufacturer. If you have any questions, please contact your local dealer or visit our website at: www.flinq.com

Safety information
Please read the following safety information before using the product. Keep it in mind for future reference. Failure to follow the instructions may result in fire, explosion, electric shock, or injury to people or pets.
Do not use the product if it is damaged or if you suspect it is damaged. Do not use the product if it is wet. Do not use the product where it may be exposed to moisture.
Do not open, disassemble, modify, or repair the product. Do not insert sharp objects into the product.
Do not expose the product to extreme temperatures, such as direct sunlight, heaters, or other heat sources. Do not leave it in a place where it may be exposed to extreme temperature.
Do not let children or pets bite, suck, or swallow the product. Do not let children or pets play with the product. Keep the product out of the reach of children and pets.
Do not use the product while driving a motor vehicle, bicycle, or any other vehicle that requires your full attention. Do not use the product while you are in a place where it is dangerous to be distracted.
Do not use the product in a place where it is prohibited to use electronic devices.
Do not use the product during a thunderstorm.
Do not use the product for long periods of time at high volume to avoid hearing damage.
Do not use the product during long periods of time at high volume for long periods!

Specifications:

Bluetooth version	V5.3
Bluetooth profile	HFP, HSP, A2DP, AVRCP
Frequency range	2402 - 2480 MHz
Maximum transmitted power	2.4 dBm
Modulation	GFSK, π/4 DQPSK, 8DPSK
Battery capacity	40 mAh
Charging time	1.5 h
Playtime	4.5 h
Charging case battery capacity	300 mAh
Charging case playtime	18 h
Charging time	2 h
Operating temperature	-10 °C - 45 °C
Storage temperature	-20 °C - 60 °C
Dimensions (W x H x D)	44 x 24 x 24 mm
Weight	4 g
Charging case dimensions (W x H x D)	62 x 44 x 24 mm
Charging case weight	45 g
Charging case material	plastic
Battery type	built-in Li-ion
USB charging	yes, type-C
Wireless charging	yes, type-C
Water resistance	IPX4

Frequency bands in which radio waves are transmitted:
2402-2480 MHz
The product complies with the following standards:
EN 62368-1:2014+A11:2017, EN 55032:2015+A11:2020, EN 55035:2017+A11:2020, EN 301 489-1 v2.2.3, EN 301 489-17 v3.1.1, EN 300 328 v2.2.2, EN 50566:2017+A1:2021, EN 62479:2010, EN 62311:2020

Highlights

- Dual on/off mesh
- Multifunction button
- Microphone
- Charging contact pin
- LED light
- Wireless charging station
- Type-C charging port

Leave danger to life by electric shock!
Do not open the housing! There are no components inside that need to be serviced by the user.
In the EU/EEA (European Union, Norway, Iceland, Liechtenstein) and Switzerland, the following applies: Do not charge batteries that are not rechargeable!
Do not short circuit the battery! Do not throw batteries into fire or water! Do not dismantle batteries!
Never let batteries lying around! Children or pets could swallow them!
Do not let the product or the battery get too hot! Do not place it near a heat source!
Do not use the product if the battery is damaged!

EU DECLARATION OF CONFORMITY
Hereby, FLINQ declares that this product complies with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity can be requested at the address: FLINQ, Postbus 246, 5830 AE Boxmeer, Netherlands. Or can be downloaded from our website: www.flinq.com

Disposal
Dispose of the product in accordance with the applicable regulations. Do not dispose of the product with your ordinary household waste. Do not dispose of the product in fire. Do not dispose of batteries in fire. Do not short circuit the battery. Do not dismantle the product or the battery. Do not dispose of the product or the battery in water. Do not dispose of batteries with your ordinary household waste. Dispose of batteries at a collection point for used batteries. Dispose of the product at a collection point for used electrical and electronic equipment. Separate the battery from the product before disposal. Ensure that the product is switched off before disposal.

Cleaning
Clean the product with a dry, lint-free cloth. Do not use any cleaning agents or abrasive materials.

Warranty
The warranty period is 24 months from the date of purchase. Keep the receipt as proof of purchase. Damage caused by improper handling or failure to follow the instructions is not covered by the warranty. Wear parts are not covered by the warranty. The battery is a wear part and is not covered by the warranty.

Contact
If you have questions about the product, please contact our customer service department: www.flinq.com/support

HOW DO I SWITCH MY EARBUDS ON?
Take the earbuds out of the charger.

HOW DO I SWITCH MY EARBUDS OFF?
Place the earbuds back into the charger and close the lid. Leave them in the charger for 5 seconds.

HOW DO I PAIR MY EARBUDS?
Take the earbuds out of the charging case. Both the left and right earbuds will automatically enter pairing mode. If the earbuds are not in pairing mode, hold the multifunction button on the earbuds for 5 seconds to enter pairing mode. Enable Bluetooth on your device and select "FLINQ CLIXX" from the list of available devices. Once paired, the earbuds will connect automatically. These can be used independently or together.

HOW DO I CONNECT MY EARBUDS TO MY DEVICE?
Ensure the earbuds are in pairing mode. Enable Bluetooth on your device and select "FLINQ CLIXX" from the list of available devices. Once paired, the earbuds will connect automatically. These can be used independently or together.

HOW DO I CHARGE MY EARBUDS?
Place the earbuds back into the charging case and close the lid. Connect the charging case to a power source using the USB-C cable provided. Alternatively, place the charging case on a wireless charger. The earbuds will start charging when they are placed in the charging case.

HOW LONG DO I CHARGE MY EARBUDS?
Charging the earbuds for 1.5 hours will provide up to 4.5 hours of playtime. The charging case can hold up to 18 hours of additional playtime. A full charge of the earbuds and the charging case takes 2 hours.

HOW LONG DO I PLAY MUSIC?
Playtime depends on the volume level and the type of music you listen to. Playtime is up to 4.5 hours with a full charge. The charging case can provide up to 18 hours of additional playtime.

HOW DO I CONTROL MY EARBUDS?
Tap the multifunction button on the earbuds to play/pause music, answer/end calls, or activate your voice assistant. Tap twice to skip forward. Tap three times to skip backward. Tap and hold to reject an incoming call. Tap and hold to activate your voice assistant. Tap and hold to enter pairing mode.

HOW DO I CHANGE MY VOLUME?
Tap the multifunction button on the earbuds to play/pause music, answer/end calls, or activate your voice assistant. Tap twice to skip forward. Tap three times to skip backward. Tap and hold to reject an incoming call. Tap and hold to activate your voice assistant. Tap and hold to enter pairing mode.

HOW DO I USE MY EARBUDS AS A HEADSET?
Take the earbuds out of the charging case. Both the left and right earbuds will automatically enter pairing mode. If the earbuds are not in pairing mode, hold the multifunction button on the earbuds for 5 seconds to enter pairing mode. Enable Bluetooth on your device and select "FLINQ CLIXX" from the list of available devices. Once paired, the earbuds will connect automatically. These can be used independently or together.

HOW DO I RESET MY EARBUDS?
Place the earbuds back into the charging case and close the lid. Leave them in the charger for 5 seconds. Take the earbuds out of the charger. Tap the multifunction button on the earbuds 5 times. Place the earbuds back into the charging case and close the lid. Take the earbuds out of the charger. Both the left and right earbuds will automatically enter pairing mode. Enable Bluetooth on your device and select "FLINQ CLIXX" from the list of available devices. Once paired, the earbuds will connect automatically. These can be used independently or together.

WHAT DOES THE LED LIGHT MEAN?
Blue: Pairing mode
Red: Battery low
Blue and red: Charging
Blue: Fully charged

WHAT DO I DO IF MY EARBUDS DO NOT WORK?
Reset the earbuds. Ensure the earbuds are charged. Ensure the earbuds are within range of your device. Ensure your device is compatible with the earbuds. Ensure your device is not connected to other Bluetooth devices. Ensure your device is not in airplane mode. Ensure your device has the latest Bluetooth version installed.

WHAT DO I DO IF MY EARBUDS DO NOT CHARGE?
Ensure the charging contacts are clean. Ensure the charging cable is not damaged. Ensure the charging cable is connected to a power source. Ensure the charging case is not damaged. Ensure the charging case has sufficient battery power.

WHAT DO I DO IF MY EARBUDS DO NOT PLAY MUSIC?
Ensure the volume is not muted. Ensure the volume is not too low. Ensure the earbuds are connected to your device. Ensure your device is not in airplane mode. Ensure your device has the latest Bluetooth version installed.

WHAT DO I DO IF MY EARBUDS DO NOT CONNECT?
Ensure the earbuds are in pairing mode. Ensure your device is not connected to other Bluetooth devices. Ensure your device has the latest Bluetooth version installed. Ensure your device is not in airplane mode. Ensure your device is compatible with the earbuds. Ensure the earbuds are within range of your device.

WHAT DO I DO IF MY EARBUDS DO NOT RECEIVE A CALL?
Ensure your earbuds are connected to your device. Ensure your device is not in airplane mode. Ensure your device has the latest Bluetooth version installed. Ensure your device is not connected to other Bluetooth devices